

Bob

Oil formation volume factor at bubble point pressure $p = P_b$:

$$(1) \quad B_{ob} = B_o(P_b)$$

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Fluid \(PVT\) Analysis](#) / [Dynamic fluid properties](#) / [Oil formation volume factor \(Bo\)](#)