

Logging Reference Point

The starting point for subsurface depth measurements.

The most popular [Logging Reference Points](#) are:

- [Rig Floor](#) (in [Open Hole Logging](#) applications)
- [Tubing Head](#) (in [Cased-Hole Logging](#) applications)
- [Rotary Table](#) (in [drilling](#) applications)
- [Kelly Bushing](#) (in [drilling](#) applications)
- [Sea Level](#) (in [geodetic](#) applications)
- [Ground Level](#) (in [geodetic](#) applications)

See Also

[Petroleum Industry](#) / [Upstream](#) / [Data Acquisition](#) / [Well & Reservoir Surveillance](#) / [Well Logging](#) / [Measured Depth](#)

[[Well & Log Analysis](#)]