

Workover = WO

[@wikipedia](#)

Hoist-aided [well Intervention](#).

Completion-orientated		Reservoir-orientated	Reactivation	Abandonment
Borehole cleaning	Milling	Water Shut-off (WSO)		
Fishing	Cement recovery	Selective Stimulation		
Replacing pump	Bottomhole drilling	Switching to another pay		
Replacing tubing	Pulling down extra casing	Conversion (producer injector)		
Replacing packer	Removing the casing	Conversion (injector producer)		
Installing a bridge plug				
Setting up the tubing /casing patch				
Pumping corrosion inhibitors				
Installing the gravel pack				
Setting up the bottom hole cement plug				

See Also

[Petroleum Industry](#) / [Upstream](#) / [Production](#) / [Subsurface Production](#) / [Well & Reservoir Management](#) / [Well Intervention](#)

[[Subsurface E&P Disciplines](#) / [Workover Engineering](#)]

[[Well](#)]