

# Downhole tool conveyance

There are different ways to convey [downhole logging tools](#) through the [wellbore](#):

Wire-line logging	
E-Coiled tubing logging	
Slick-line logging	
Coiled tubing logging	
Tractor logging	