

Water injection rate = qWI

Surface flowrate of total injected water measured at SPE Standard Conditions (STP).

Symbol	Metric unit	Oilfield unit
$q_{WI}^{\downarrow}$	cmd	bpd

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing \(WT\)](#) / [Flowrate Testing](#) / [Flowrate](#)

[[Well & Reservoir Surveillance](#)]

[[Surface flowrates](#)] [[Oil surface flowrate](#)] [[Gas surface flowrate](#)] [[Water surface flowrate](#)]

[[Sandface flowrates](#)] [[Oil sandface flowrate](#)] [[Gas sandface flowrate](#)] [[Water sandface flowrate](#)] [[Total sandface flowrate](#)]

[[Cumulative water injection \(\$Q_{WI}^{\downarrow}\$ \)](#)]