

Injection rate

Depending on context may mean:

$q_{WI}^{\downarrow}$	Water injection rate
$q_{GI}^{\downarrow}$	Gas injection rate
$q_i^{\uparrow}$	Total sandface flowrate in injecting well

and sometimes denoted as $q^{\downarrow}$

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing \(WT\)](#) / [Flowrate Testing](#) / [Flowrate](#)

[[Production rate](#)]