

Cumulative oil production = QO

Synonym: Cumulative oil production (Q_O) = Recovered Oil

Total production of oil from the beginning of production t_0 until current moment of time t :

(1)
$$Q_O^\uparrow(t) = \int_{t_0}^t q_O^\uparrow(\tau) d\tau$$

where

$q_O^\uparrow(\tau)$	oil production rate at time moment τ
----------------------	---

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing \(WT\)](#) / [Flowrate Testing](#) / [Flowrate](#)

[[Well & Reservoir Surveillance](#)]

[[Surface flowrates](#)] [[Oil surface flowrate](#)] [[Gas surface flowrate](#)] [[Water surface flowrate](#)] [[Liquid production rate](#)]