

Initial formation temperature = T_i

Formation temperature T_i before the well was put on stream: $T_i = T_e(t < 0)$

See also

[Natural Science](#) / [Geoscience](#) / [Geology](#) / [Rock](#)

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / <http://nafta.wiki/x/LYBPB>

[[Reservoir pressure](#)] [[Formation pressure, \$P_e\$](#)] [[Drilled formation pressure, \$P_d\$](#)] [[Startup formation pressure, \$P_0\$](#)]

[[Initial formation pressure \(\$P_i\$ \)](#)]