

Oil Sandface Productivity Index

Productivity Index of the oil phase across the well-reservoir contact:

(1)
$$J_o = \frac{q_o}{p_{e,o} - p_{wf}}$$

where

q_o	Oil sandface flowrate
$p_{e,o}$	Oil phase formation pressure
p_{wf}	Sandface bottom hole pressure