

Water Sandface Productivity Index

Productivity Index of the water phase across the well-reservoir contact:

(1)
$$J_g = \frac{q_g}{p_{e,g} - p_{wf}}$$

where

q_w	Water sandface flowrate
$p_{e,w}$	Water phase formation pressure
p_{wf}	Sandface bottom hole pressure