

Oil Surface Productivity Index

Productivity Index of dead oil with surface flowrate measured at separator

(1)
$$J_O = \frac{q_O}{p_r - p_{wf}}$$

where

q_O	Oil surface flowrate
p_r	Field-average formation pressure
p_{wf}	Sandface bottom hole pressure

See also

[Surface Productivity Index](#)