

Pressure Drawdown

Pressure difference between [formation pressure](#) p_e and wellbore flowing pressure p_{wf} at sandface:

$$\Delta p = p_e - p_{wf}$$

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing](#) / [Pressure Testing](#) / [Pressure Transient Analysis \(PTA\)](#) / [PTA Diagnostic Plot](#)

[[Well & Reservoir Surveillance](#)] [[Pressure Diffusion](#)] [[Pressure drop](#)]