First Barrier (1st Barrier) in well logging

Identifies the first pipeline in which a downhole logging tool is moving during well logging

The downhole tool usually starts well logging through tubing which represents the First Barrier here and when the tool moves below tubing shoe the casing becomes a First Barrier.

See Also

Petroleum Industry / Upstream / Subsurface E&P Disciplines / Well & Log Analysis