

Subsurface Well Tests

Flowrate and pressure measurements taken below wellhead:

Open-Hole Well Tests	Cased-Hole Well Tests
DST – Drill Stem Test	Downhole Flowmeter
WFT – Wireline Formation Test	SGS – Static Gradient Survey
	PTA – Pressure Transient Analysis

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing](#)

[[Well & Reservoir Surveillance](#)]