

Cross-well Pressure Test

[Flowrate](#) and [pressure](#) measurements taken at two or more [wells](#) with account of their interference:

PIST – Pressure Interference Step Test (as version of PTA)
PICT – Pressure Interference Pulse Test (as version of PTA)

See Also

[Petroleum Industry](#) / [Upstream](#) / [Data Acquisition](#) / [Well & Reservoir Surveillance](#) / [Cross-well Surveillance](#)