

Wellbore radius (rw)

The average radius of [OH wellbore](#):

(1)
$$r_w = \sqrt{\frac{A_w}{\pi}}$$

where

A_w	OH wellbore cross-sectional area after drilling
-------	---

See Also

[Petroleum Industry](#) / [Upstream](#) / [Well](#)