

Dynamic variables in Upstream

The most popular examples in [Upstream](#) are:

Reservoir temperature	Reservoir pressure	Reservoir saturation	Well flowrates
$T(t, \mathbf{r})$	$p(t, \mathbf{r})$	$s(t, \mathbf{r})$	$\{q_o(t), q_g(t), q_w(t)\}$

See also

[System](#) / [Dynamic System](#) / [Dynamic variable](#)