

Multihase Fluid Mobility

In [multiphase flow](#) the concept of [total fluid mobility](#) is not well-defined as [phases](#) may have different [mobilities](#) and flow quite independently from each other, having different [phase pressures](#), moving at different [velocities](#) and segregated in space.

In most popular case of a [3-phase Oil + Gas + Water fluid model](#) with relatively homogeneous flow ([phases](#) may move at different [velocities](#) but occupy the same reservoir space and have the same [phase pressure](#)) the [multi-phase mobility](#) may be defined by [Perrine model](#):

$(1) \quad M = k_{air} \cdot \left[M_{rw} + \left(1 + \frac{R_s B_g}{B_o} \right) \cdot M_{ro} + \left(1 + \frac{R_v B_o}{B_g} \right) \cdot M_{rg} \right]$	$\Rightarrow$	$(2) \quad \left\langle \frac{k}{\mu} \right\rangle = k_{air} \cdot \left[\frac{k_{rw}}{\mu_w} + \left(1 + \frac{R_s B_g}{B_o} \right) \cdot \frac{k_{ro}}{\mu_o} + \left(1 + \frac{R_v B_o}{B_g} \right) \cdot \frac{k_{rg}}{\mu_g} \right]$
---	---------------	--

In case of [2-phase Oil + Water fluid model](#) with regular to small values of R_s (when [Perrine model](#) makes the most practical sense):

$(3) \quad M = k_{air} \cdot [M_{rw} + M_{ro}]$	$\Rightarrow$	$(4) \quad \left\langle \frac{k}{\mu} \right\rangle = k_{air} \cdot \left[\frac{k_{rw}}{\mu_w} + \frac{k_{ro}}{\mu_o} \right]$
---	---------------	---

See also

[Physics](#) / [Fluid Dynamics](#) / [Percolation](#)

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Field Study & Modelling](#) / [[Complex reservoir properties](#)] [[Basic diffusion model parameters](#)]

[[Petrophysics](#)] [[Basic reservoir properties](#)] [[Permeability](#)] [[Absolute permeability](#)] [[Relative permeability](#)] [[Wettability](#)] [[Phase mobility](#)] [[Relative phase mobilities](#)]

[[Linear Perrine multi-phase diffusion @model](#)]