

Imbibition

Sweeping a non-wetting phase by wetting phase

Oil is non-wetting phase for the most non-petroleogenetic rocks so that water flood is imbibition process

blocked URL

Fig. 1. Illustration of primary and secondary Drainage and Imbibition.

See also

[Physics](#) / [Fluid Dynamics](#) / [Percolation](#) / [Sweeping](#)

[[Wettability](#)] [[Drainage](#)]