

Pore Pressure

Synonym: [Reservoir Pressure](#) = [Pore Pressure](#)

[Fluid pressure](#) in a given location $\mathbf{r}$ of a [subsurface reservoir](#) and a given moment of time t : $p(t, \mathbf{r})$

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#)

[[Formation pressure](#)]