

Waterflood Recovery Quality

One of the metrics of [Waterflood Recovery](#) efficiency.

(1)
$$\text{WFQ} = \frac{Q_{O,WF}}{Q_{O, NDR}}$$

where

$Q_{O,WF}$	cumulative oil production under Waterflood Recovery conditions
$Q_{O, NDR}$	cumulative oil production under Natural Depletion Recovery conditions

See also

[Petroleum Industry](#) / [Upstream](#) / [Production](#) / [Field Development Plan](#) / [Recovery Methods](#) / [Waterflood Recovery \(WF\)](#)