

Borehole Injection Profile = BIP

Borehole Flow Profile (BFP) in injecting wells.

Log Name	QZI, QZIW, QZIG
Math Symbol	q_h, q_{hw}, q_{hg}
Model	PLT-BFP Model
Units	
SI	m ² /s
Oil Metric	m ² /d
Oil Field	bbl/ ft

See Also

[Petroleum Industry](#) / [Upstream](#) / [Data Acquisition](#) / [Well & Reservoir Surveillance](#) / [Well logging](#) / [Cased-Hole Logging](#) / [Production Logging \(PLT\)](#) / [Borehole Flow Profile \(BFP\)](#)

[[Well & Log Analysis](#)] [[Reservoir Flow Profiling \(RFP\)](#)] [[Temperature Flow Logging](#)] [[Borehole Production Profile](#)]

[[PLT – Donwnhole Tools](#)] [[PLT – Logging Procedure](#)] [[PLT – Interpretation](#)] [[PLT – Samples](#)]