

Decommission

Synonym: [Abandoned Petroleum Field](#) = [Decomission](#)

[Petroleum Field](#) that has stopped [production](#) with all [wells](#) being [Plugged and Abandoned](#) and the [Field](#) being signed off from [Balance Sheet](#) as an [Economic Asset](#).

The main reason for abandonment is poor [remaining recoverable reserves](#) but may also be a result of various [production](#) complications, whether technical or social.

See also

[Petroleum Industry](#) / [Upstream](#) / [Petroleum Asset](#) / [Petroleum Field](#)

[[Oil Field](#)] [[Gas Field](#)]

[[Appraisal Field](#)] [[New Field](#)] [[Trial Production Field](#)] [[Green Field](#)] [[Brown Field](#)] [[Mature Field](#)] [[Converted Field](#)] [[Abandoned Field](#)]