

Booster FDP

Specific [Field Development Planning](#) which aims at maximum production acceleration and usually assumes the following principles:

- drilling producers only in the zones of the maximum residual reserves
- reducing BHP in producers to the minimal value
- increasing THP in injectors to the maximum value
- workovers are focused on production maintenance only

This [FDP](#) is usually exercised at the end of the economical [production](#) and right before [Decomission](#).

The [Booster FDP](#) may not be the most economical and reaching the highest recovery.

See also

[Petroleum Industry](#) / [Upstream](#) / [Production](#)

[Subsurface E&P Disciplines](#) / [Field Development Planning](#)

[[NFA FDP](#)][[Reference FDP](#)]