

Specific Flowrate

Flowrate normalized by effective formation thickness

(1)
$$\langle q \rangle_h = \frac{q}{h}$$

where

$\langle q \rangle_h$	specific flowrate
q	flowrate
h	effective formation thickness