

Sandface pressure response

[Bottomhole pressure](#) across the [well-reservoir contact](#)

The usual abbreviation is p_{wf} (sometimes p_{sf})

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing](#) / [Pressure Testing](#)