

# First Barrier (1st Barrier) in well logging

Identifies the first pipeline in which a downhole logging tool is moving during [well logging](#)

The downhole tool usually starts [well logging](#) through [tubing](#) which represents the [First Barrier](#) here and when the tool moves below [tubing shoe](#) the casing becomes a [First Barrier](#).

## See Also

---

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well & Log Analysis](#)