

Single-Well Tests

[Flowrate](#) and [pressure](#) measurements taken at one selected [well](#) only:

Flowrate Testing
SGS – Static Gradient Survey
DST – Drill Stem Test
WFT – Wireline Formation Test
Drawdown Test (DD) (as version of PTA)
Injection Test (INS) (as version of PTA)
Build-up Test (BUS) (as version of PTA)
Fall off Test (FOS) (as version of PTA)
MRST – Multirate Step Test (as version of PTA)
SPT – Self-Pulse Test (as version of PTA)

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Well Testing](#)

[[Well & Reservoir Surveillance](#)]