

True Vertical Depth (TVD)

@wikipedia

Downward [elevation](#) of a given point with reference to the [logging reference point](#):

$$\text{TVD} = \text{TVDSS} + \text{Logging Reference Elevation}$$

It is widely used in [Subsurface Engineering](#).

See also

[Natural Science / Physics / Measuring / Positioning](#)

[[Subsurface Engineering](#)] [[Altitude](#)]