

# Zonal Flow Analysis

---

- Location of inflow zones
- Location of calibration zones (based on flow stability)
- Location of calculation zones (based on flow stability)
- Locate cross-flow zones (based on temperature and raw FBS data)

---

Location of inflow zones

Location of calibration zones (based on flow stability)

Location of calculation zones (based on flow stability)

Locate cross-flow zones (based on temperature and raw FBS data)