

Sandface

The contact area between [wellbore](#) and [subsurface reservoir](#)

When used for calculating [dynamic fluid properties](#) it means that [pressure](#) and [temperature](#) are at [subsurface reservoir](#) conditions