

Water-Oil Corey curvature (nwo)

Default value is $n_{wo} = 2$

See also

[Physics](#) / [Fluid Dynamics](#) / [Percolation](#)

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Field Study & Modelling](#)

[[Petrophysics](#)] [[Basic reservoir properties](#)] [[Wettability](#)] [[Permeability](#)] [[Absolute permeability](#)] [[Relative permeability](#)] [[Water permeability](#)] [[Water relative permeability](#)] [[Water-oil relative permeability \(krwo\)](#)]