

In-Casing Cross-Flow (ICX)

Specific type of [Downhole cross-flow](#) occurring inside the casing or tubing through:

borehole communication between perforations

borehole communication between the leaks and perforations or between the leaks
--

See Also

[Petroleum Industry](#) / [Upstream](#) / [Petroleum Well](#) / [Downhole cross-flow](#)

[[Well Drilling](#)] [[Well completion](#)] [[Production \(well flow status\)](#)] [[Injection \(well flow status\)](#)] [[Flowing \(well flow status\)](#)] [[Shut-in \(well flow status\)](#)]