

Stock-Tank Gas Initial In-Place = STGIIP

[@wikipedia](#)

Volumetric value of [Gas Initial In Place \(GIIP\)](#) recalculated to [NTP](#) conditions.

The estimation algorithm is based on [STGIIP @model](#).

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / [Petroleum Reservoir](#) / [Gas Initial In Place \(GIIP\)](#)

[[Surface Tank Hydrocarbon Initial In Place \(STHCIIP\)](#)] [[Stock-Tank Oil Initial In-Place \(STOIIP\)](#)]