

Surface Tank Hydrocarbon Initial In Place = STHCIIP

[@wikipedia](#)

Volumetric value of current (remaining) [Hydrocarbon Initial In Place \(HCIIP\)](#) recalculated to [NTP](#) conditions and represented by two numbers: { [Stock-Tank Oil Initial In-Place \(STOIIP\)](#) , [Stock-Tank Gas Initial In-Place \(STGIIP\)](#) }

The above formula does not have a practical meaning as [Petroleum Production](#), accounting and sales are managed separately for [Oil](#) and [Gas](#).

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / [Petroleum Reservoir](#) / [Petroleum Reservoir Fluids](#) / [Hydrocarbon Initial In Place \(HCIIP\)](#)

[[Stock-Tank Oil Initial In-Place \(STOIIP\)](#)] [[Stock-Tank Gas Initial In-Place \(STGIIP\)](#)]