

Cross-well deconvolution = XDCV

Specific type of [Multiwell deconvolution \(MDCV\)](#) applied to the analysis of interference between one well with [BHP](#) records and off-set wells which also have [BHP](#) records the [XDCV @model](#) is used.

See also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Production Analysis \(PA\)](#) / [Pressure Deconvolution](#) / [Multiwell deconvolution \(MDCV\)](#)

[[MDCV @model](#)] [[XDCV @samples](#)]