

Oil Initial In Place = OIIP = Oil Original In Place = OOIP

[@wikipedia](#)

Refers to subsurface volume of all [oil](#) initially present in [Petroleum Reservoir](#) before the [anthropogenic invasion](#).

The volumetric value of [OIIP](#) in [NTP](#) conditions is given by [STOIIP](#).

The changes in volume and structure of [OIIP](#) over time can be caused by production from a given [petroleum reservoir](#) or by [hydrocarbons](#) migration caused by production from the offset [hydrodynamically connected petroleum reservoirs](#).

For the current volume and distribution of [oil](#) after the [anthropogenic invasion](#) refer to [Oil In Place \(OIP\)](#).

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / [Petroleum Reservoir](#) / [Petroleum Reservoir Fluids](#) / [Hydrocarbon Initial In Place \(HCIIP\)](#)

[[Exploration](#)] [[Booking Reserves](#)] [[Oil Initial In Place \(OIIP\)](#)] [[Stock-Tank Oil Initial In-Place \(STOIIP\)](#)] [[Mobile Oil Initial In-Place \(MOIIP\)](#)]

[[Oil In Place \(OIP\)](#)]