

Oil-water capillary pressure

Pressure difference between [oil phase](#) and [water phase](#) in [subsurface reservoir](#):

(1)
$$P_{cow} = p_o - p_w$$

where

See also

[Capillary pressure](#)