

MDCV @model

[RDCV @model](#)

[XDCV @model](#)

If the case is built around analysing the interference between one well with **BHP** readings and off-set wells without **BHP** records the [RDCV @model](#) is used.

If the case is built around analysing the interference between one well with **BHP** readings and off-set wells which also have **BHP** records the [XDCV @model](#) is used.

See also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Production Analysis \(PA\)](#) / [Pressure Deconvolution](#) / [Mult iwell deconvolution \(MDCV\)](#)

[[RDCV @model](#)][[XDCV @model](#)]