

Initial rate = q0

Initial value of the [flowrate](#) historical data record:

t	t₀	t ₁	t ₂	...
q	q₀	q ₁	q ₂	...

See Also

[Petroleum Industry](#) / [Upstream](#) / [Production](#) / [Subsurface Production](#) / [Production/Injection History](#)

[[Production Analysis](#)]