

# Water-Oil Rate Plot = qOW

The plot of [water production rate](#)  $q_W$  (along y-axis) against the [oil production rate](#)  $q_O$  (along x-axis).

It can be used for express [Watercut Diagnostics](#) of thief water production.

The mathematical model of the thief water production from [aquifer](#) is based on the following equation:

|                             |                                               |                                        |
|-----------------------------|-----------------------------------------------|----------------------------------------|
| (1) $q_W = a \cdot q_O + b$ | (2) $a = J_{1O}^{-1} \cdot (J_{1W} + J_{2W})$ | (3) $b = J_{2W} \cdot (p_2^* - p_1^*)$ |
|-----------------------------|-----------------------------------------------|----------------------------------------|

where

|         |                                                           | $q_W$    | water production rate                                           | $q_O$    | oil production rate                                           |
|---------|-----------------------------------------------------------|----------|-----------------------------------------------------------------|----------|---------------------------------------------------------------|
| $p_1^*$ | formation pressure in <a href="#">petroleum reservoir</a> | $J_{1W}$ | water productivity index of <a href="#">petroleum reservoir</a> | $J_{1O}$ | oil productivity index of <a href="#">petroleum reservoir</a> |
| $p_2^*$ | formation pressure in <a href="#">aquifer</a>             | $J_{2W}$ | water productivity index of <a href="#">aquifer</a>             |          |                                                               |

For the case of [aquifer](#) pressure is higher than that of [petroleum reservoir](#):  $b > 0 \Leftrightarrow p_2^* > p_1^*$

For the case of [aquifer](#) pressure is lower than that of [petroleum reservoir](#):  $b < 0 \Leftrightarrow p_2^* < p_1^*$

In practical applications, the equation (1) is often considered through the [weighted average](#) values:

(4)  $\langle q_W \rangle = a \cdot \langle q_O \rangle + b$

where

|                                            |                                         |
|--------------------------------------------|-----------------------------------------|
| $\langle q_W \rangle, \langle q_O \rangle$ | are weighted average of $q_W$ and $q_O$ |
|--------------------------------------------|-----------------------------------------|

There are different ways to calculate [weighted average](#) of the dynamic variable, for example:

| t-weighted average                                   | q-weighted                                                   |
|------------------------------------------------------|--------------------------------------------------------------|
| $\langle A \rangle_t = \frac{1}{t} \int_0^t A(t) dt$ | $\langle A \rangle_q = \frac{1}{Q(t)} \int_0^t A(t) q(t) dt$ |

## See Also

[Petroleum Industry](#) / [Upstream](#) / [Production](#) / [Subsurface Production](#) / [Field Study & Modelling](#) / [Production Analysis](#) / [Watercut Diagnostics](#)