

Effective porosity = PHIE

@wikipedia

A **pore volume** V_ϕ fraction of **bulk rock volume** V_r containing the **hydrodynamically connected fluids** (also called **free fluids**) within each **pore** element:

(1)
$$\phi_e = \frac{V_\phi}{V_r}$$

The **log** name is **PHIE**.

The reason to introduce this concept is that a part of the actual inter-grain void is filled with shale thus reducing the actual volume available for fluids.

It splits into two components:

Open porosity ϕ_{opn}	Closed porosity ϕ_{cls}
with interconnected pores	with isolated pores

subject to condition:

(2)
$$\phi_e = \phi_{\text{opn}} + \phi_{\text{cls}}$$

Effective porosity is a function of **reservoir pressure** at a given location $p(\mathbf{r})$:

(3)
$$\phi_e(\mathbf{r}, p) = \phi_{ei}(\mathbf{r}) \exp \left[\int_{p_i}^p c_\phi(p) dp \right]$$

where

$c_\phi(p)$	pore compressibility (see also Pore compressibility @model)
$\phi_{ei} = \phi_e(p_i)$	effective porosity at the initial formation pressure p_i
p_i	initial formation pressure

This leads to the effect of **Porosity Shrinkage**.

Since the **pore compressibility** is very low ($\sim c = 0.5 \div 1.5 \text{ GPa}^{-1}$) and has a weak dependence on **reservoir pressure** for **subsurface rocks** in **petroleum reservoirs** the (3) can be written as:

(4)
$$\phi_e(\mathbf{r}, p) = \phi_{ei}(\mathbf{r}) \cdot \left[1 + c_\phi (p - p_i) + 0.5 c_\phi^2 (p - p_i)^2 \right]$$

Most **Subsurface E&P Disciplines** (except **Petrophysics**) usually omit index "e" and denote **Effective porosity** as $\phi = \phi_e$.

See also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petrophysics \(PP\)](#) / [Volumetric Rock Model](#)

[[Basic reservoir properties](#)] [[Pore volume](#)] [[Connected pore volume](#)] [[Closed pore volume](#)] [[Porosity](#)] [[Open porosity](#)] [[Closed porosity](#)] [[Initial Porosity \$i\$](#)]

[[Pore compressibility @model](#)]