

Drainage area (Ae)

The area around a [producing](#) or [injecting well](#) where [reservoir fluid](#) is forced moving by the well operation.

In other words, the area, where [reservoir fluid](#) is moving along the [streamlines](#) which either stem from [injecting well](#) or end up at [producing well](#).

For [homogeneous reservoir](#) it can be estimated as:

(1)
$$A_e = \frac{V_e}{h_e \phi_e}$$

where

V_e	drainage volume
$h_e = \text{const}$	effective formation thickness
$\phi_e = \text{const}$	effective porosity

It is often related to [drainage radius](#) r_e as:

(2)
$$A_e = \pi r_e^2$$

which can be is misnomer for other shapes of [drainage area](#).

See also

[Physics](#) / [Fluid Dynamics](#) / [Percolation](#)

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Field Study & Modelling](#) / [Drainage \(fluid flow\)](#)

[[Drainage volume \$V_e\$](#)] [[Drainage radius \(\$r_e\$ \)](#)]