

Normalized Vaporized Oil Ratio (Rvn)

$$R_{vn} = \frac{R_v B_o}{B_g}$$

where

R_v	Vaporized Oil Ratio
B_o	Oil formation volume factor
B_g	Gas formation volume factor

See Also

[Petroleum Industry / Upstream / Subsurface E&P Disciplines / Fluid \(PVT\) Analysis](#)

[Cross-phase exchange ratios \(Rs and Rv\)](#)