

Gas In Place = GIP

[@wikipedia](#)

Refers to all [natural gas](#) currently present in [Petroleum Reservoir](#).

The volumetric value of [GIP](#) in [NTP](#) conditions is given by [STGIIP](#).

The changes in volume and structure of [GIP](#) over time can be caused by production from a given [petroleum reservoir](#) or because of the [hydrocarbons](#) migration caused by production from the offset [hydrodynamically connected petroleum reservoirs](#).

For the initial volume and distribution of [natural gas](#) existed before the [anthropogenic invasion](#) refer to [Gas Initial In Place \(GIIP\)](#).

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / [Petroleum Reservoir](#) / [Petroleum Reservoir Fluids](#) / [Hydrocarbon In Place \(HCIP\)](#)

[[Exploration](#)] [[Booking Reserves](#)] [[Gas Initial In Place \(GIIP\)](#)] [[Gas In Place \(GIP\)](#)] [[Stock-Tank Gas In-Place \(STGIP\)](#)] [[Movable Gas Initial In-Place \(MGIIP\)](#)]