

Normalized Pseudo-Pressure = P

$$(1) \quad P_\Psi(p) = \frac{p_{ref} \cdot \Psi(p)}{\Psi(p_{ref})} = p_{ref} \cdot \int_0^p \frac{p \, dp}{\mu(p) Z(p)} \Big/ \int_0^{p_{ref}} \frac{p \, dp}{\mu(p) Z(p)}$$

where

p_{ref}	reference pressure
$\Psi(p_{ref})$	Pseudo-Pressure at reference pressure p_{ref}
$\Psi(p)$	Pseudo-Pressure at pressure p
$\mu(p)$	dynamic fluid viscosity
$Z(p)$	fluid compressibility factor

It is widely used in Pressure Diffusion @model and transient data analysis (PTA / RTA) of strongly compressible fluids.

The choice of reference pressure p_{ref} is made by engineer depending on common sense and objectives of the study.

The usual practise is to select $p_{ref} = p(t = 0)$ as the bottom-hole pressure at initial time moment.

In case the Normalized Pseudo-Pressure is used to linearize the Pressure Diffusion equation the choice of reference pressure is not going to affect the solution.

Normalized Pseudo-Pressure does represent a pressure in terms of physical property and has the same dimension unlike Pseudo-Pressure.

See also

Physics / Mechanics / Continuum mechanics / Fluid Mechanics / Fluid Dynamics / Pressure Diffusion / Pressure Diffusion @model

Petroleum Industry / Upstream / Subsurface E&P Disciplines / Well Testing / Pressure Testing

[Pseudo-Pressure]