

# Dew point = (Td, Pd)

A pair of  $(T_d, P_d)$  of Dew point pressure ( $P_d$ ) and Dew point temperature ( $T_d$ ) at which the phase transition between liquid and gaseous states of the matter ( condensation / vaporization ) starts happening.

## See also

---

[Petroleum Industry / Upstream / Subsurface E&P Disciplines / Fluid Analysis \(PVT\) / Dynamic fluid properties](#)

[\[ Dew point pressure \( \$P\_d\$ \) \]\[ Dew point temperature \( \$T\_d\$ \) \]](#)