

# Watercut Diagnostics

**Synonym:** [Watercut Diagnostics](#) = [WOR Diagnostics](#)

Part of [Production Analysis](#) related to analyzing the [production watercut](#) dynamics and the possible reasons of its specific behaviour:

regular displacement, bottom-water encroachment, coning, thief water production via channeling or tubing /casing failure.

	Time-based	Saturation-based	Recovery-based	Cum water-based	Rate-based	Injection-based
<b>Saturation</b>		<a href="#">Watercut Fractional Flow plot</a>				
<b>Recovery</b>			<a href="#">WOR vs Recovery plot</a>			<a href="#">WOR vs WOBR</a>
<b>Bad Water</b>	<a href="#">Chan water plot</a>	<a href="#">Watercut Fractional Flow plot</a>		<a href="#">WW plot + Y Y plot</a>	<a href="#">qOW plot + WOIL plot + YLIQ plot</a>	<a href="#">WOR vs NWR</a>
<b>Non-uniform Sweep</b>		<a href="#">Watercut Fractional Flow plot</a>		<a href="#">WW plot + Y Y plot</a>	<a href="#">qOW plot + WOIL plot + YLIQ plot</a>	
<b>Waterflood pattern</b>				<a href="#">WW plot + Y Y plot</a>		

## See Also

[Petroleum Industry](#) / [Upstream](#) / [Production](#) / [Subsurface Production](#) / [Field Study & Modelling](#) / [Production Analysis](#)

[ [Good Water](#) ] [ [Bad Water](#) ] [ [Water cut \(Yw\)](#) ] [ [WOR](#) ]

[ [Watercut \(Yw\) Fractional Flow @model](#) ] [ [Watercut Chan plot](#) ]

[ [Waterflood Diagnostics](#) ] [ [WOR vs WOBR @model](#) ] [ [WOR vs NWR @model](#) ]