

STOIP @model

[@wikipedia](#)

Volumetric value of [Oil In Place \(OIP\)](#) recalculated to [NTP](#) conditions:

(1)
$$V_{\text{STOIP}} = \int_{\Omega} \left[\frac{s_o(\mathbf{r})}{B_o} + \frac{R_v s_g(\mathbf{r})}{B_g} \right] \phi_e(\mathbf{r}) dV$$

where

Ω	Petroleum reservoir
$\mathbf{r} = (x, y, z)$	Position vector to some location in a reservoir
$dV = dx dy dz$	Volume element of a reservoir
$p_i(\mathbf{r}), T_i(\mathbf{r})$	Initial formation pressure and temperature at location $\mathbf{r}$
$\phi_e(\mathbf{r})$	Effective porosity at location $\mathbf{r}$
$s_o(\mathbf{r}), s_g(\mathbf{r})$	Current Oil saturation and Gas saturation at location $\mathbf{r}$
$B_o(p_i, T_i), B_g(p_i, T_i)$	Oil FVF and Gas FVF at Initial formation pressure and temperature
$R_s(p_i, T_i), R_v(p_i, T_i)$	Solution GOR and Vaporized Oil Ratio at Initial formation pressure and temperature

For practical implementation of [\(1\)](#) one needs to build a [Dynamic Flow Model \(DFM\)](#) and perform a numerical integration.

See Also

[Petroleum Industry](#) / [Upstream](#) / [Subsurface E&P Disciplines](#) / [Petroleum Geology](#) / [Petroleum Reservoir](#) / [Hydrocarbon In Place \(HCIP\)](#) / [Oil In Place \(OIP\)](#) / [Stock-Tank Oil In-Place \(STOIP\)](#)